

IMPORTANT:

Must mount with at least ½ inch spacing between each unit.
Do not exceed 12 units mounted per KD-SMS16



2U Models

KD-X222PO
KD-Fix418A
KD-Fix418

3U Models

KD-X444S / KD-X444L
KD-X444SP / KD-X444LP
KD-EX18G
KD-CX800
KD-IP1080Tx / KD-IP1080Rx

4U Models

KD-X422POA
KD-X40MRx

5U Models


KD-PS22UTx
KD-X100MRx
KD-MC1000
KD-IP922ENC / KD-IP922DEC
KD-IP822ENC / KD-IP822DEC
KD-IP1022ENC / KD-IP1022DEC

5U (continued)

KD-S2x1 / KD-S2x1X
KD-S4x1 / KD-S4x1X
KD-DA1x2 / KD-DA1x2X
KD-DA1x4 / KD-DA1x4X
KD-Amp220

IMPORTANT:

Must mount with at least ½ inch spacing between each unit.
Do not exceed 12 units mounted per KD-SMS16



2U Models

KD-X222PO
KD-Fix418A
KD-Fix418

3U Models

KD-X444S / KD-X444L
KD-X444SP / KD-X444LP
KD-EX18G
KD-CX800
KD-IP1080Tx / KD-IP1080Rx

4U Models

KD-X422POA
KD-X40MRx

5U Models

KD-PS22UTx
KD-X100MRx
KD-MC1000
KD-IP922ENC / KD-IP922DEC
KD-IP822ENC / KD-IP822DEC
KD-IP1022ENC / KD-IP1022DEC

5U (continued)

KD-S2x1 / KD-S2x1X
KD-S4x1 / KD-S4x1X
KD-DA1x2 / KD-DA1x2X
KD-DA1x4 / KD-DA1x4X
KD-Amp220

IMPORTANT:

Must mount with at least ½ inch spacing between each unit.

Do not exceed 12 units mounted per KD-SMS16

Compatible Models:

Extenders:

KD-X222PO
KD-X444S / KD-X444L
KD-X444SP / KD-X444LP
KD-X422POA
KD-SX440 Rx
KD-EX18G
KD-X40MRx
KD-PS22UTx
KD-X100MRx

Control:

KD-CX800
KD-MC1000

AV over IP:

KD-IP1080Tx / KD-IP1080Rx
KD-IP922ENC / KD-IP922DEC
KD-IP822ENC / KD-IP822DEC
KD-IP1022ENC / KD-IP1022DEC

Switchers:

KD-S2x1 / KD-S2x1X
KD-S4x1 / KD-S4x1X

Distribution Amplifiers:

KD-DA1x2 / KD-DA1x2X
KD-DA1x4 / KD-DA1x4X

HDMI Fixers:

KD-Fix22 / KD-Fix418A
KD-Fix418

Amplifiers:

KD-Amp220



IMPORTANT:

Must mount with at least ½ inch spacing between each unit.

Do not exceed 12 units mounted per KD-SMS16

