



Discover The Possibilities™



Honeywell Vista Security Module Setup

About:

Honeywell Vista provides security that can protect any home or office from theft. Honeywell offers a large selection of Vista Security Panels and accessories that can issue safety to any area.

Setup Communication:

Honeywell Vista Panels are controlled over RS-232. Compass Control supports RS-232 communication through Honeywell's serial interface (Honeywell Connected Building Module, Model: 4232CBM). Please note that the Honeywell serial interface is required to control the Honeywell Vista Panel.

The Honeywell serial interface is connected to the Master Controller by RS-232. A regular 3.5mm male to male stereo cable must be stripped and installed into the 4232CBM module. Please wire TX, RX, and GND from the cable to the Honeywell serial interface. Next, using the provided Yellow/Green/Black/Red cable found with the 4232CBM, attach the connector to the serial interface and install to the Vista Honeywell Panel as if it was a Keypad. The iOS device will now act as a virtual keypad through the Compass Control App.

Setup Complete:

Upload and update project for use.

Control:

Compass Control offers

- Honeywell Security Control
 - Bi-Directional Feedback
 - Arm/Disarm Control
 - Area/Zone Status