



Aprilaire RS Thermostat

Module Setup

About:

The Aprilaire Thermostat is an electronic, and programmable thermostat that can be controlled from anywhere in the home using RS-232 communication.

Setup Communication:

Aprilaire Thermostat is controlled over RS-232. In Compass Navigator, insert Aprilaire module and add it to the System Designer tree. Please note that if more Thermostats are required, add an additional thermostat module.

Setup Compass Navigator:

If additional thermostats are included in the system, add multiple modules. Once added, click on each thermostat page and look at the events and actions associated with the page. Edit the variable change and set *ThermostatID* to correspond to the ID assigned in the programming of each thermostat.

Setup Complete:

Upload and update project for use.

Control:

Compass Control offers

- Aprilaire Thermostat Controls
 - Thermostat Mode
 - Thermostat Set Points
 - Thermostat Fan Mode
 - Thermostat Eco Savings
 - Thermostat Sensors